



SWITCH POSITIONS	
1	OFF
2	PHONO
3	AM NORMAL
4	AM HI-FI
5	FM
6	TV

FRONT AND REAR OF SWITCH VIEWED  
 FRONT OR XMBE END OF SWITCH IN EXTREME  
 COUNTER-CLOCKWISE POSITION (OFF POSITION).

- NOTE**
- ALL RESISTORS TO BE 1/2 WATT, 5% UNLESS OTHERWISE SPECIFIED.
  - ALL CAPACITORS WITH DECIMAL VALUES ARE IN MFD AND ARE PAPER CAPACITORS, 400VDCV, UNLESS OTHERWISE SPECIFIED.
  - ALL CAPACITORS WITH WHOLE NUMBER VALUES ARE IN MFD AND ARE CERAMIC CAPACITORS, UNLESS OTHERWISE SPECIFIED.

# Bogen R-701